

### mini-Ligno E/D

Before taking a measurement remove the green cap and place it on the other end of the meter. The cap fits your hand for easy pin insertion. To obtain a reading, push pins into wood. As soon as on-off switch is depressed, red numbers indicate moisture readings. For deeper measurements use longer pins (stored in the back of the case).

Moisture readings are indicated in percent and corrected for a wood temperature of 70°F (20°C). For higher or lower wood temperatures use correction table in manual. Most common wood species and corresponding wood groups are listed on the back. Contact customer service for unlisted woods.

Check/change wood group setting: Wait until meter turns itself off. Then double click on-off switch between pins by hand. A red LED indicates wood group 2 or 3. While wood group is displayed, click on/off switch again to change wood group. Wait until meter turns off before taking readings

When LED lights get dim, exchange 9 Volt battery. Remove screw on back, open into 2 halves.

**Lignomat USA Ltd** 14345 NE Morris Ct.  
Portland OR, 97230 USA  
[www.lignomat.com](http://www.lignomat.com)  
e-mail: [sales@lignomat.com](mailto:sales@lignomat.com)  
Tel: 800-227-2105 503-257-8957

### Wood Groups for mini-Ligno E/D

#### Woodgroup 2

Abachi  
Acacia  
Afrormosia  
Bamboo  
Beech  
Cedar (all types)  
Cumaru  
Dogwood  
Gonzales Alves  
Iroko  
Jatoba  
Koa  
Locust  
Oak Red / White  
Poplar  
Ramin  
Rosewood  
Teak  
Wenge  
Zebra Wood  
Hardboard  
OSB  
Waferboard

#### Woodgroup 3

Alder  
Ash  
Aspen  
Balsa  
Basswood  
Birch  
Cherry  
Cottonwood  
Cypress  
Elm  
Fir Douglas  
Gum  
Hemlock  
Hickory  
Kempas  
Larch  
Lauan (white / red)  
Mahogany  
Maple  
Meranti (dark / red)  
Merbau  
Myrtlewood  
Oak European  
Pine  
Pine Southern Yellow  
Redwood  
Spruce  
Tigerwood  
Walnut  
Particleboard